


BOSCH 150A ALTERNATOR KIT FOR TOYOTA/LEXUS 1G-FE ENGINES INSTALLATION GUIDE

Contents :




1. Bosch alternator 150A
2. Tension bracket
3. M10 bolt
4. Upper bracket
5. 2 x M8 bolt
6. 2 x M10 bolt with washers
7. Alternator connector
8. Toyota OEM connector
9. Spacer

Bosch alternator pinout :

L - Alt. Charge Warning Light

DFM - Battery Voltage Sense



L DFM

Installation :

1. Take off the OEM Toyota alternator.
2. Screw the upper bracket (4) to the Bosch alternator 150A (1) using bolts 5 & 6 (do not tighten yet!) as seen in photo 1.



Photo 1

3. Screw the tension bracket (2) with the spacer (9) to the OEM tensioner using bolt (5) as seen in photo 2.



Photo 2

4. If needed, bend or cut off the bracket in circle as seen in photo 3.




Photo 3

5. Screw the alternator with upper bracket to the engine using bolt (3) and to the tension bracket using bolt (6).
6. Put belt on, tension it and tighten bolts. Due to so many different applications, accessories and pulley diameters, we cannot supply a universal belt. In our case, we used a 4PK 1160 belt.

A doubt? A question?

*Do not hesitate to contact us at **+33 185 086 186** or by email **contact@driftshop.com***