



BOSCH 140A & 180A ALTERNATOR KIT FOR TOYOTA 1JZ & 2JZ ENGINES INSTALLATION GUIDE




Contents:



Note: Items 12 & 13 are options for rear oil pan

- 1. Bosch alternator
- 2. Upper mount bracket
- 3. M10 Allen bolt
- 4. 2 x spring washer
- 5. 3 x washer
- 6. M8 Allen bolt
- 7. M10 Allen bolt
- 8. M10 bolt
- 9. M10 not
- 10. Alternator connector
- 11. Low mount spacer
- 12. Bigger low mount bracket (rear oil pan)
- 13. 2 x bigger low mount bracket bolts
- 14. Toyota / Lexus harness connector

Toyota OEM harness pinout:



- L Alt. Charge Warning Light
- IG Ignition Switch
- S Battery Voltage Sense

Toyota OEM harness pinout:



L - Alt. Charge Warning Light DFM - Battery Voltage Sense



Installation:

- 1. Take off the OEM alternator and remove the pin from the engine block.
- 2. Install the upper mount bracket (2) to the top mount of the alternator with bolt (6) and (7). Bolt (6) replaces the water pump bolt (photo 1).




Photo 1

3. Only for rear sump oil pan: install larger low mount bracket (12) onto the oil pan with 2 bolts (13), do not tighten yet (photo 2).



Photo 2

- 4. Put spring washer (4) and washer (5) on M10 bolt (8).
- 5. Install the alternator (1) to the lower bracket with bolt (8). Do not tighten yet (photo 3).





Photo 3

- 6. Use bolt (3) with washers (4 & 5) to mount the alternator on the upper mount bracket (2).
- 7. Tighten all bolts in sequence: 13 (optional), 3, 8.
- 8. Add washer (5) to the back of bolt (8) and tighten with nut (9) (photo 4).



Photo 4

9. Put the belt back on. Due to so many different applications, accessories and pulley diameters, we cannot supply a universal belt. You will need to use your current belt, or source a new one from a generic automotive supplier if yours needs replacement.

A doubt? A question?

Do not hesitate to contact us at +33 185 086 186 or by email contact@driftshop.com