

POWERFLEX®

PART NUMBER

PFF60-801

DESCRIPTION

FRONT ARM FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 1 x PTFE/Silicone Grease
- 2 x Polyurethane B Bushes
- 2 x Stainless Steel Sleeves
- 2 x Zinc Plated Mild Steel Shells

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the arm.
2. Clean any dirt and corrosion from the bore of the arm and file off any sharp edges.
3. Push the outer shell into the bore of the arm from the rear of the car until the smallest diameter meets the end of the flat face of the arm.
4. Push the A part into the outer shell from the front of the car, and push the B part into the outer shell from the rear of the car. The two bushes should meet in the middle of the outer shell.
5. Apply some of the supplied grease to the bore of the bushes and insert the sleeve into the bore.
6. Tension all hardware to manufacturers recommended torque settings.

