

### INSTALLATION GUIDE

#### **Product description:**

This part replaces the original bush; OEM part number 50521929.

#### **Contents (parts per pack):**

4 x Polyurethane bushes  
2 x Stainless steel sleeves

4 x Washers  
1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
  - all safety precautions adhered to;*
  - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the original bush from arm.
2. Clean any dirt and corrosion from the bore in the arm.
3. Insert polyurethane bush into arm with top hat section facing outwards.
4. Apply the supplied grease to the bore and mounting sides of each bush.
5. Insert stainless steel sleeve into polyurethane bush.
5. Fit supplied mounting washers on inside of the bracket.
6. Insert arm with fitted bush between washers.
7. Fit original bolt through bush and tighten.
8. Refit arm. Tension all hardware to manufacturers recommended torque settings.

